



**Innox IGS 33-55-77  
Guitar stand  
Mounting instructions**

**CAUTION**

Ensure the tripod is placed on a stable, level surface to prevent tipping. Do not exceed the maximum load capacity to avoid structural damage. Always check that all locks are securely tightened before use. Store the tripod in a dry, cool place to prevent damage from moisture or extreme temperatures. Ensure that you use the correct bolts and screws in their designated places. Using the wrong bolts in the wrong locations can affect the stability of the tripod. Always carefully check the assembly instructions and use the provided parts as indicated."

**Contents of the box**

1. Neck rest
2. Tightening bolt
3. Vertical supporting tube
4. Leg tube
5. Mounting screw
6. Nut and wash
7. Bolt and wash
8. Guitar body rest



**Contact:**

Innox hardware & accessories  
Verrijn Stuartweg 18  
4462 GE Goes  
The Netherlands

*Please do not send any products directly to this address. If you wish to return a product for a refund or repair, please contact your local dealer for an RMA (Return Material Authorisation).*

