

# V-Pianoエディター インストール・ガイド


© 2009 ローランド株式会社

本書の一部、もしくは全部を無断で複写・転載することを禁じます。



## V-Pianoエディターとは？

V-Pianoエディターは、お手持ちのパソコンとV-PianoをUSBケーブルで接続して、V-Pianoのトーン・パラメーターをパソコンでリアルタイムにカスタマイズすることができるソフトウェアです。



## V-Pianoエディターのインストール方法

### インストールの前に...

以下の項目をチェックします

- V-Pianoエディターの動作条件をご確認ください。V-Pianoエディターの動作条件は、CD-ROM内の「ReadMeJ.txt」に記載されています。
- すべてのソフトウェアおよびウイルス・チェッカーなどの常駐ソフトウェアを終了してください。
- 必ず管理者権限でパソコンにログオンしてください。

- 1 付属のCD-ROM をパソコンに入れます。
- 2 CD-ROM 内の「Installer」フォルダにある「setup (.exe)」（Mac OS Xの場合は「V-Piano Editor Installer.pkg」）をダブルクリックします。

Windows XPの場合 Windows Vistaの場合 Mac OS Xの場合



setup




setup



V-Piano Editor  
Installer.pkg

- 3 画面の指示に従ってインストールします。

## V-Pianoエディターの起動

- Windows XPまたは、Windows Vistaの場合  
スタート・メニューから、「すべてのプログラム→V-Piano Editor→V-Piano Editor」をクリックします。
- Mac OS Xの場合  
 「アプリケーション」の「Roland」 - 「V-Piano Editor」フォルダにあるアイコンをダブルクリックします。

※ Microsoft、Windowsは、米国Microsoft Corporationの米国及びその他の国における登録商標です。

※ Windows® の正式名称は、Microsoft® Windows® operating systemです。

※ Apple、Macintosh、Mac OSは、米国Apple Inc.の米国及びその他の国における登録商標です。

※ 文中記載の会社名及び製品名は、各社の商標または登録商標です。

## お使いになる前に

### V-Pianoエディターの使いかたについて


V-Pianoエディターでのトーンのカスタマイズ方法については、V-Pianoのオンライン・ドキュメントをご覧ください。

V-Pianoエディターを起動した状態で、V-Pianoエディターの「ヘルプ→V-Piano Editorの使いかた」を実行すると、オンライン・ドキュメントが表示されます。

### MIDIの設定について

V-Pianoエディターの初回起動時は、MIDIの設定をしてください。

V-Pianoエディターの「MIDI機器の設定」で、V-PianoのInput/OutputにV-PianoのMIDIポートを選択します。




※ 図はWindows Vistaの場合の例です。

※ ThroughのInput/Outputには、なにも選択しないでください。

※ インストール直後の起動時のみ、MIDIの設定をする必要があります。次回以降の起動時は、再度設定する必要はありません。

### V-Pianoのトーン設定の読み込みについて

V-Pianoエディターを起動したら、最初に「[Read] ボタンをクリックしてください。V-Piano本体のトーンの設定が、V-Pianoエディターに読み込まれます。




# V-Piano Editor Installation Guide

Copyright © 2009 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

## What is V-Piano Editor?

V-Piano Editor is software that allows you to use your personal computer to customize the V-Piano's tone parameters in real time—after you have connected the V-Piano to your computer using a USB cable.



## Installing V-Piano Editor

### Before you begin the installation...

Please take note of the following things

- Check to make sure that your computing environment meets the requirements for V-Piano Editor. Refer to "ReadMe.txt" on the CD-ROM for details.
- Make sure to close all software, including virus protection software and any other resident programs.
- You must log on to your computer using an account that has administrative privileges.

- 1 Insert the supplied CD-ROM into your computer.
- 2 Double-click "setup(.exe)" (or, in Mac OS X, "V-Piano Editor Installer.pkg"), which can be found in the "Installer" folder on the CD-ROM.

Windows XP users



setup

Windows Vista users



setup

Mac OS X users



V-Piano Editor  
Installer.pkg

- 3 Perform the installation by following the instructions that appear on screen.

## Starting up V-Piano Editor

### ● With Windows XP or Windows Vista

From the Start menu, click "All Programs" – "V-Piano Editor" – "V-Piano Editor."

### ● With Mac OS X



V-Piano Editor

Double-click the icon in the "Roland" – "V-Piano Editor" folder, located within "Applications."

## Before you begin using the software

### Using V-Piano Editor


Refer to the online documentation for the V-Piano for instructions on how to customize tones using V-Piano Editor.

Once V-Piano Editor has been launched, all you need to do to view the online documentation is to select "Help–V-Piano Editor Manual."

### Concerning the MIDI settings

You'll need to make the settings necessary for using MIDI the first time that you launch V-Piano Editor.

In V-Piano Editor, under "Set Up MIDI Devices," you need to select the V-Piano's MIDI ports for the Input/Output of the V-Piano.




- \* The above depicts what you should see in Windows Vista.
- \* Do not select anything for the Input/Output of "Through."
- \* The settings necessary to use MIDI need to be made only once, immediately after you have started up the software for the first time.

### Loading the V-Piano's tone settings

Before you start customizing any tones using V-Piano Editor, you first need to acquire all the settings for tones that are stored inside the V-Piano itself.

After starting up V-Piano Editor, the first thing you need to do is click the [Read] button. When you do this, all the tone settings stored inside the V-Piano instrument will be loaded into V-Piano Editor.



- \* Microsoft and Windows are registered trademarks of Microsoft Corporation.
- \* Windows® is known officially as: "Microsoft® Windows® operating system."
- \* Apple, Macintosh and Mac OS are registered trademarks of Apple Inc.
- \* All product names mentioned in this document are trademarks or registered trademarks of their respective owners.