



# 9.5 CONTROL PANEL SECTION (2/3)


1 2 3 4

A • Bottom view

• Top view



Refer to "9.6 CONTROL PANEL SECTION (3/3)".



1 2 3 4

## CONTROL PANEL SECTION (2/3) SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	LVMB Assy	DWX4048	
2	MXRB Assy	DWX4051	A
3	DCK1 Assy	DWX4054	
4	MEQB Assy	DWX4055	
5	RECB Assy	DWX4056	
6	CHF1 Assy	DWX4057	
7	CHF2 Assy	DWX4058	
8	DCK2 Assy	DWX4062	
9	DKHD Assy	DWX4066	
10	Connector Assy	PF03PP-B05	
11	FFC/39P	DDD1687	B
12	FFC	DDD1813	
13	FFC	DDD1745	
14	FFC/17P	DDD1684	
15	FFC/15P	DDD1660	
16	FFC/19P	DDD1689	
17	Power Knob	DAC2306	
18	Slide SW Cap (W)	DAC2401	
19	SW Cap	DAC2753	
20	Cap	DAC3136	C
21	Insulating Sheet	DEC3594	
22	Barrier	DEC3742	
23	Barrier	DEC3743	
24	VR Stay S	DNH2964	
25	Stay	DNH3297	
26	Stay	DNH3300	
27	Bracket	DNH3312	
NSP 28	Guide Shaft VK1	DLA1978	
29	Lever Plate	DNH2954	D
30	VR Stay	DNH2955	
31	Slider Base	DNK5851	
32	Shaft Holder	DNK5852	
33	•••••		
34	•••••		
35	Screw	BBZ30P060FTC	
36	Screw	BPZ20P060FTC	
37	Screw	BPZ30P080FNI	
38	Screw	BSZ20P040FTB	E
39	Screw	CPZ26P080FTC	
40	Screw	PMH20P040FTC	