vezzpa

-MASTER VOLUME-

-SUSTAIN-



-FUZZZZ-
FUZZ MODE ON

-STINGER-
HIGH OCTAVE MODE ON

-OUTPUT-

-INPUT-

2.1MM +9VDC JACK

CENTER NEGATIVE POLARITY

MULTI FUNCTION SWITCH

1X- EFFECT ON/OFF

2X- SWITCH BETWEEEN MODES

HOLD- MOMENTARILY SWITCHES BETWEEN MODES

-ON/OFF INDICATOR-

BEEWARE!: BEETRONICS WILL REPAIR/ REPLACE ANY MALFUNCTIONING PRODUCT WITHIN A YEAR OF THE PURCHASE DATE. ANY DAMAGE CAUSED BY MODIFICATIONS OR MISUSE MAY CANCEL THIS WARRANTY.

PEDAL DIMENSIONS:
4-1/2" X 2-1/2" X 2-1/4"

CURRENT DRAW - 36mA

MADE IN CALIFORNIA

Family Beeyness

WWW.BEETRONICSFX.COM

vezzpa

As the name states this is no ordinary bee. It's actually a wasp, a nasty and agressive one with an opamp heart that can produce an extreme high pitched buzz.
On FUZZZZ mode you get a big wall of fuzz, great for the coolest riffs and power chords. Turn down the SUSTAIN control to get a spitty fuzzing tone, or turn it up for a gated super high gain fuzz. On STINGER mode this wasp gets agressive, bringing up the high octave and cutting through the mix. Harmonics on crack best defines it!
Its multi function switch allows you to select between the modes or access them momentarily giving you multiple options to buzz.
Bee ready to get high on honey tones!

MULTI FUNCTION SWITCH OPERATION

When in bypass:
- SINGLE CLICK will turn the effect on.
- HOLD will momentarily turn the effect on.

When already engaged:
- SINGLE CLICK will turn effect off.
- DOUBLE CLICK will switch between modes.
- HOLD will momentarily switch between modes.

In order for the Vezzpa footswitch to process multiple functions, the SINGLE CLICK action needs to be no longer than 250ms. In other words you should make it a quick click, otherwise it may recognize as a HOLD. If you rather have a longer SINGLE CLICK there's a way to restart the pedal with a 350ms SINGLE CLICK. Keep in mind that this will raise the latency when using the hold function to switch between modes.

LAZY BEE MODE - Unplug the power supply. Hold the footswitch down and connect the power. The lights will blink between the FUZZZZ and STINGER leds. After a couple of seconds with it blinking, let go of the footswitch and the pedal is set to LAZY BEE MODE. Now your SINGLE CLICK can be up to 350ms long.
To go back to the standard FAST BEE MODE simply remove the power cable turning it off and turn it back on.