



**FAZLEY**

**CHR-01**  
**“Chorus Chrissy”**

Contact:  
Fazley Musical Instrument Products and Accessories  
Verrijn Stuartweg 18  
4462 GE Goes  
The Netherlands

**Specifications**

Input Impedance: 100 kohm  
Output Impedance: 150 ohm on max Volume  
Recommended Load Impedance: 10 kohm  
Equival Input Noise: -90 dBu or less  
Current Draw: 5.5 mA (DC 9V)  
Dimension: 94mm x 42mm x 48mm  
Weight : 133g



### AC/DC Adapter Jack

Use only specified AC adapter, and connect it to an AC outlet of the correct voltage.

### Volume Knob

This knob adjusts the volume of the effect sound. Rotating the knob clockwise turn up the volume, while rotating it counterclockwise will turn down the volume.

### Speed Knob

This controls the speed of Chorus effect. Rotating the knob clockwise the speed of Chorus will be faster, while rotating it counterclockwise the speed will be slower.

### Input Jack

This jack accepts signals from a guitar or other effect pedals.




### Depth Knob

This adjusts the depth of effect sound. Rotating it clockwise increases the depth, whereas counterclockwise rotation reduces the depth.

### Output Jack

Connect this jack to your amp or to the input of another effect pedal.



### Pedal Switch

This switch turns the effect ON/OFF.

### ON/ OFF LED

Indicates effect or bypass status of the effect pedal. When the LED is lit up, the effect is active.

